POSPrinter 80 Simple Driver

1. Operating environment

The software supports the following x86-based operating systems

- Windows 11

- Windows 10

- Windows 8

- Windows 7

- Windows 2003

- Windows Vista

- Windows XP

2. Drive installation

2.1. Double-click the. exe file to begin the installation

POSPrinterSimp
le80DriveSetup
V2.0R.exe

2.2 Start Installation

2.2.1 Set As Server Default

2.2.2. Select Printer Interface
    Select one option from USB, serial port, parallel port, or network port. Please ensure that the port is connected

2.2.3. Click the 'Start to install printer driver' button to install

2.2.4. Installation by Using the Installation Wizard
    Click the text at the bottom of the interface to jump to the manual installation page

3. Other instructions

3.1 Installation Failure

Please open with administrator privileges and disable antivirus software or set it as a trusted file.

3.2. Unable to Print

Please check the connection with the printer.

3.3. Port Selection

Open the Control Panel, go to Devices and Printers, right-click on the printer, select 'Printer Properties', find the port selection, and click the Apply button.